Printer ACTIVE WEAR



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2262049 Fastpitch RSX**

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
body lenght CB		71	73	75	77	79	81	82	83
1/2 chest		53	56	59	63	67	71	75	79
Sleevelenght		66	67,5	69	71	73	75	76	77

All measurements are indicative with minimum tolerance of 1 cm